





















	Original	Rechange	Original	Rechange
	Power			
	Mute			
	Tv/AV			
	Multimedia			
	I/II			
	List			
	ARC			
	Menu			
	PR+			
	PR-			
	Up			
	Down			
	Right			
	Left			
	OK			
	Vol+			
	Vol-			



