

















































Original	Recharge
PP	PP
	 Back / Return
	 Power
1	1
	 1
2	2
	 2
3	3
	 3
4	4
	 4
5	5
	 5
6	6
	 6
7	7
	 7
8	8
	 8
9	9
	 9
P<P	P<P
	 Fav / Marker / PC
0	0
	 0
--	--
	 Guide / EPG / -/--
	 Menu / Home
	 Info / Angle
I-II	I-II
	 Audio / Lang I/II

Original	Recharge
	 Mute / Dimmer
	 Left
	 Up
	 Right
	 OK
	 Down
	 Vol-
	 Vol+
	 CH- / Page-
	 CH+ / Page+
	 Red / Netflix / Search
	 Red / Sound / Title
	 Green / APP / Repeat
	 Green / Picture / Format
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Text / Goto



