



Original		Recharge		Original		Recharge	
	Power		Power		-[J]- / S.STD		Shift + Dual
	Sleep		Sleep		Menu		Menu
	Mute		Mute		Up		Up
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Right		Right
	4		4		Down		Down
	5		5		Vol +		Vol +
	6		6		Vol -		Vol -
	7		7		Program +		Ch +
	8		8		Program -		Ch -
	9		9		Exit		Exit
	0		0		Open / Close		Eject
	10+ / Aspect		Shift + Guide		Info		Info
	Subtitle		Subt		Setup / DVD / FAV		Options
	Source		AV		I/II / Audio		Dual
	-[/]- / P.STD		Shift + Format		[/≡] / Text		Text





	Original	Recharge	Original	Recharge
	Play	 Play		Blue
	Pause	 Pause		
	Stop	 Stop		
	[≡x] / EPG	 Guide		
	[≡◆] / Title / ADD	 TV/R		
	Menu / SUB.	 D. Menu		
	[≡+] / Goto	 Format		
	[≡?] / Slow	 Smart		
	[≡o] / Repeat	 3D		
	[≡i] / A-B	 Media		
	I<<	 I<<		
	Red	 Red		
	>>I	 >>I		
	Green	 Green		
	<<	 <<		
	Yellow	 Yellow		
	>>	 >>		
				

