



































































































Original		Rechange		Original		Rechange	
	Standby		Power		P+		Ch +
	Source		AV		P-		Ch -
	1		1		Menu		Menu
	2		2		Guide		Guide
	3		3		Tools		Options
	4		4		Info		Info
	5		5		Return / Back		Back
	6		6		Exit		Exit
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	TTX/MIX		Text		Left		Left
	PRE-CH		Pre Ch		Smart Hub		Smart
	Mute		Mute		Red		Red
	Vol+		Vol +		Green		Green
	Vol-		Vol -		Yellow		Yellow





Original		Recharge		Original		Recharge	
	Blue		Blue				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	>>		>>				
	>>		>>				
	<<		<<				
	<<		<<				
	AD/Subt.		Subt				
	3D		3D				
	History		Format				
	Support		Dual				
	Camera		Shift + Smart				
	D		TV/R				
	CH List		List				

