





































































Original	Recharge	Original	Recharge
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 Up / CH+	 Up
 1	 1	 Up / CH+	 Ch +
 2	 2	 Down / CH-	 Down
 3	 3	 Down / CH-	 Ch -
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 Right	 Right
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 ALT / <<	 Smart
 0	 0	 ALT / <<	 <<
 FAV	 Pre Ch	 List / >>	 List
 SUB	 Subt	 List / >>	 >>
 Menu	 Menu	 Red / I<< / Lang	 Red
 EPG	 Guide	 Red / I<< / Lang	 I<<
 Info	 Info	 Red / I<< / Lang	 Dual



