



Original	Recharge
DAT/TAPE1	Shift + Red / Netflix /
TAPE2	Shift + Green / APP /
<< Deck A	Down
<< Deck B	Shift + Down
< Deck B	Shift + Left
< Deck A	Left
> Deck B	Shift + Right
> Deck A	Right
>> Deck B	Shift + Up
>> Deck A	Up
TAPE3	Shift + Yellow / YouTube /
Stop Deck A	OK
Stop Deck B	Shift + OK
Pause Deck B	Shift + Pause / Step /
Deck B Rec	Shift + Stop /
Rec Deck A	Rec / Rec Mode
Rec Deck B	Shift + Rec / Rec Mode

Original	Recharge
AUX	Yellow / YouTube / Repeat
Tuner Preset +	Shift + >>I / Preset+
Tuner Preset +	CH+ / Page+
CD	Red / Netflix / Search
Tuner Preset -	Shift + I<< / Preset-
Tuner Preset -	CH- / Page-
Tuner	Green / APP / Repeat
1 Tuner	1
2 Tuner	2
3 Tuner	3
4 Tuner	4
5 Tuner	5
6 Tuner	6
7 Tuner	7
8 Tuner	8
9 Tuner	9
0 Tuner	0





Original		Recharge		Original		Recharge	
	1 CD	+	Shift + 1		Attenuator -		Vol-
	2 CD	+	Shift + 2				
	3 CD	+	Shift + 3				
	4 CD	+	Shift + 4				
	5 CD	+	Shift + 5				
	6 CD	+	Shift + 6				
	7 CD	+	Shift + 7				
	8 CD	+	Shift + 8				
	9 CD	+	Shift + 9				
	10 CD	+	Shift + 0				
	CD I<<		I<< / Preset-				
	CD >>I		>>I / Preset+				
	CD Play		Play / Slow				
	Phono		Blue / Prime Video / Random				
	CD Stop		Stop / Hold				
	CD Pause		Pause / Step / Freeze				
	Attenuator +		Vol+				

