







































































Original		Rechange		Original		Rechange	
	Power		Power		Up		Ch +
	Mute		Mute		Down		Down
	1		1		Down		Ch -
	2		2		Left		Left
	3		3		Left		Vol -
	4		4		Right		Right
	5		5		Right		Vol +
	6		6		OK		Ok
	7		7		Menu		Menu
	8		8		Exit		Exit
	9		9		EPG		Guide
	0 / TV/SAT		0		i		Info
	0 / TV/SAT		TV/R		Text		Text
	Audio		Dual		FAV / Red		Red
	Page+		>>I		FAV / Red		Pre Ch
	Page-		I<<		Sleep		Sleep
	Up		Up		AUD / Green		Green



