




Original	Rechange
 Power	 Power
 □□	 SHIFT + 1 Shift + 1
 →•	 SHIFT + 2 Shift + 2
 ↓	 SHIFT + 3 Shift + 3
 ↑	 SHIFT + 4 Shift + 4
 ↘	 SHIFT + 5 Shift + 5
 ↙	 SHIFT + 6 Shift + 6
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Rechange
 1-	 GUIDE Guide
 2-	 FAV PRE-CH Pre Ch
 ? C/P	 SHIFT + GUIDE Shift + Guide
 C/P	 SHIFT + FAV PRE-CH Shift + Pre Ch
 Red / Sat	 A Red
 MEMO Green+ / Memo	 B Green
 Up / Size	 Up
 +1 Yellow+ / +1	 C Yellow
 Blue / ←	 D Blue
 Size	 PICTURE FORMAT Format
 IN Green- / Left / IN	 Left
 IN Green- / Left / IN	 SHIFT + B Shift + Green
 /01 Yellow- / Right /01	 SHIFT + C Shift + Yellow
 /01 Yellow- / Right /01	 Right
 Text / Mix / i	 REPEAT TEXT Text
 Text / Mix / i	 DISPLAY INFO Info
 Down	 Down





	Original	Rechange		Original	Rechange
	000	 Shift + 0			
	P+	 Ch +			
	P-	 Ch -			
	→ ←	 Smart			
	C	 Shift + Exit			
	[1-2]VO	 Dual			
	E	 Exit			
	Mute	 Mute			
	*	 I<<			
	●	 <<			
	•	 >>			
	▲	 Subt			
	+	 Vol +			
	-	 Vol -			

