







































































Original		Recharge		Original		Recharge	
	Power		Power		prime video		Shift + Media
	Smart		Smart		Home		Shift + Smart
	1		1		Menu		Menu
	2		2		Back		Back
	3		3		Exit		Exit
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	Info		Info		Mute		Mute
	Guide		Guide		CH+		Ch +
	Netflix		Media		CH-		Ch -
	YouTube		Options		Source		AV
	Google Play		3D		Red		Red





	Original	Rechange	Original	Rechange
	Green	B		
	Yellow	C		
	Blue	D		
	<<			
	Play			
	>>			
	Rec			
	Pause			
	Stop			
	Text			
	Subt			
	Audio			

