




































Original		Rechange		Original		Rechange	
	Power		Power		Mute		Mute
	Test		Guide		Settings		Options
	6 ch direct/Stereo 1		1				
	Stereo 2		2				
	Stereo 3		3				
	Optical 1		4				
	Optical 2		5				
	coaxial		6				
	Sub+		Ch +				
	Sub-		Ch -				
	Center+		Up				
	Center-		Down				
	Surround+		Right				
	Surround-		Left				
	Effect		Smart				
	Volume+		Vol +				
	Volume-		Vol -				

