







































































Original		Recharge		Original		Recharge	
	Standby		Power		Reload		Back
	F1		3D		EPG		Guide
	Shift		Smart		V+		Vol +
	Mute		Mute		V-		Vol -
	Pause		Pause		Info		Info
	<<		<<		FAV		Pre Ch
	>>		>>		CH+		Ch +
	Record		Rec		CH-		Ch -
	Play		Play		1		1
	Stop		Stop		2		2
	Menu		Menu		3		3
	Exit		Exit		4		4
	Up		Up		5		5
	Left		Left		6		6
	OK		Ok		7		7
	Right		Right		8		8
	Down		Down		9		9



