







































































| Original  |             | Rechange  |                        | Original  |         | Rechange  |                  |
|---|-------------|---|------------------------|---|---------|---|------------------|
|    | Power       |    | Power                  |    | Right   |    | Right            |
|    | VGA         |    | Red / Netflix / Search |    | Vol+    |    | Vol+             |
|    | AV1         |    | Shift + 1              |    | Vol-    |    | Vol-             |
|    | AV2         |    | Shift + 2              |    | Mute    |    | Mute / Dimmer    |
|    | AV3         |    | Shift + 3              |    | CH/PR+  |    | CH+ / Page+      |
|    | Brightness+ |    | >> / Tune+             |    | CH/PR-  |    | CH- / Page-      |
|    | Brightness- |    | << / Tune-             |    | 1       |    | 1                |
|    | Contrast+   |    | >>I / Preset+          |    | 2       |    | 2                |
|    | Contrast-   |    | I<< / Preset-          |    | 3       |    | 3                |
|    | Zoom On/Off |    | Zoom / Size            |    | 4       |    | 4                |
|   | Zoom In     |   | Sleep / Timer          |   | 5       |   | 5                |
|  | Zoom Out    |  | TV/Radio /             |  | 6       |  | 6                |
|  | Menu        |  | Menu / Home            |  | 7       |  | 7                |
|  | OK          |  | OK                     |  | 8       |  | 8                |
|  | Up          |  | Up                     |  | 9       |  | 9                |
|  | Down        |  | Down                   |  | 0       |  | 0                |
|  | Left        |  | Left                   |  | AV Mute |  | AV / Input / RDS |



