







































































Original	Rechange	Original	Rechange
 Mute	 Mute / Dimmer	 ↔	 Smart / List
 Power	 Power	 -/-	 Guide / EPG / -/-
 [ ]/[+]	 TV/Radio /	 0	 0
 Input	 AV / Input / RDS	 C	 Fav / Marker / PC
 [=]	 Text / Goto	 [  ]/[=]	 Display / Media
 [X]/[o]	 Zoom / Size	 Red	 Red / Netflix / Search
 1	 1	 Green	 Green / APP / Repeat
 2	 2	 Yellow	 Yellow / YouTube / Repeat
 3	 3	 Blue	 Blue / Prime Video / Random
 [◆]	 Picture / Format	 Menu	 Menu / Home
 4	 4	 +	 Up
 5	 5	 Vol+	 Vol+
 6	 6	 Progr+	 CH+ / Page+
 [?]/[i+]	 Subtitle / EQ	 →←	 OK
 7	 7	 -	 Down
 8	 8	 Vol-	 Vol-
 9	 9	 Progr-	 CH- / Page-











