Mandis shop

REMCON2034



Original		Rechange		Original	Rechange
LIGHT ON/OFF	Light/On/Off		Power		
FAN OFF	Fan/Off	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1H	1H	TV 1	1		
2H	2H	DVD 2	2		
4H	4H	CD - STB 3	3		
LOW	Low		Down		
MED	Med	OK	OK		
HIGH	High		Up		



https://remote-controls.ch/fr/UNKNOWN/1068975-96483-telecommande-de-remplacement-pour-UNKNOWN-REMCON2034.html