



















Original	Recharge	Original	Recharge
 Up	 Up		
 Left	 Left		
 OK	 OK		
 Right	 Right		
 Down	 Down		
 Menu	 Menu / Home		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		

