






















































Original		Rechange		Original		Rechange	
	Power		Power		Recall		Back / Return
	Mute		Mute / Dimmer		Red		Red / Netflix / Search
	P.Mode		Picture / Format		Green		Green / APP / Repeat
	S.Mode		Sound / Title		Yellow		Yellow / YouTube / Repeat
	Sleep		Sleep / Timer		Blue		Blue / Prime Video / Random
	Audio		Audio / Lang I/II		Menu		Menu / Home
	1		1		Up		Up
	2		2		Source		AV / Input / RDS
	3		3		Left		Left
	4		4		OK / Enter		OK
	5		5		Right		Right
	6		6		Exit		Exit / Cancel / Clear
	7		7		Down		Down
	8		8		Info		Info / Angle
	9		9		CH+		CH+ / Page+
	Freeze		Pause / Step / Freeze		Home		Shift + Menu /
	0		0		Vol+		Vol+





	Original	Recharge		Original	Recharge
	CH-	CH- / Page-		Zoom-	+  Shift + Down
	Mouse	Smart / List		Zoom+	+  Shift + Up
	Vol-	Vol-		EPG	Guide / EPG / -/-
	<< / Text	<< / Tune-		DTV / Radio	TV/Radio /
	<< / Text	Text / Goto		Rec	Rec / Rec Mode
	>> / Hold	+  Shift + Stop /		Subtitle	Subtitle / EQ
	>> / Hold	>> / Tune+			
	I<< / Mix	I<< / Preset-			
	I<< / Mix	+  Shift + Text /			
	>>I / Reveal	>>I / Preset+			
	Play/Pause / Index	Play / Slow			
	Stop / Size	Stop / Hold			
	Stop / Size	Zoom / Size			
	FAV	Fav / Marker / PC			
	Aspect	+  Shift + Picture / Format			
	File	Display / Media			
	Delete	Eject / Surround			

