



































Original		Recharge	
	Standby		Power
	Mute		Mute / Dimmer
	Play / Pause		Pause / Step / Freeze
	Play / Pause		Play / Slow
	AUX		7
	Line / Bluetooth		9
	>> / Search+		>> / Tune+
	I<< / Radio-		I<< / Preset-
	Stop		Stop / Hold
	>>I / Radio+		>>I / Preset+
	Repeat /		Green / APP / Repeat
	<< / Search-		<< / Tune-
	USB / Tuner		6
	Vol-		Vol-
	CH. Level		Smart / List
	Vol+		Vol+
	Loudne		Sound / Title

Original		Recharge	
	EQ		Subtitle / EQ
	Mo / St		Audio / Lang I/II
	Scan		Display / Media

