




















































































































Original	Recharge	Original	Recharge
 Power	 Power	 Left Up	 Vol +
 Mute	 Mute	 Left Down	 Vol -
 Clock	 Sleep	 Right Up	 Ch +
 12 Hrs	 Smart	 Right Down	 Ch -
 24 Hrs	 Media	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Up/Dn	 Options
 6	 6	 *)	 Dual
 7	 7	 ±10s	 Subt
 8	 8	 INT	 3D
 9	 9	 FGB	 Format
 0	 0	 TBT	 TV/R
 Exit	 Exit	 Timer	 AV
 Edit	 Pre Ch		

Original	Recharge	Original	Recharge
 Left Up	 Vol +	 TV	 AUX
 Left Down	 Vol -	 DVD	 MUTE
 Right Up	 Ch +	 SAT	 SHIFT
 Right Down	 Ch -	 PLAY MODE	 REC MODE
 Up	 Up	 ▶	 ⏸
 Down	 Down	 ■	 ●
 Right	 Right	 ⏩	 ⏪
 Left	 Left	 DISC NAV	 SOUND
 OK	 Ok	 AD	 SETTINGS
 Up/Dn	 Options	 LIST	 DUAL
 *)	 Dual	 SUBT	 OPT
 ±10s	 Subt	 PROG	 SEARCH
 INT	 3D	 PICTURE	 ECO
 FGB	 Format	 SLEEP	 TV/R
 TBT	 TV/R	 E-MANUAL	 REPEAT
 Timer	 AV	 ZOOM	 TIMER
		 TEXT	 AV
		 TOP MENU	 DISPLAY
		 MENU	 INFO
		 OK	 EXIT
		 HOME	 RETURN
		 VOL +	 BACK
		 SMART	 APP
		 MEDIA	 CH +
		 CH -	 1
		 2	 3
		 3	 4
		 4	 5
		 5	 6
		 6	 7
		 7	 8
		 8	 9
		 9	 0
		 0	 FAV
		 GUIDE	 PRE-CH
		 A	 B
		 C	 D
		 Mandis SHOP	 www.mandis.tv

