







































































Original	Rechange
 Power	 Power
 Mute	 Mute
 Play	 Play
 [=]	 Text
 Pause/[/≡]	 Pause
 Stop/[≡+]	 Stop
 Rec/[≡◆]	 Rec
 <</[≡0]	 <<
 <</[≡]	 <<
 >> /[≡?]	 >>
 >>/[≡x]	 >>
 ANT	 Subt
 Tools	 Options
 1	 1
 2	 2
 3	 3
 4	 4

Original	Rechange
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Back	 Back
 Home/Source	 Smart
 Home/Source	 AV
 Vol+	 Vol +



