















































Original	Recharge
PP	PP
	 Back / Return
 Power	 Power
1	1
	 1
2	2
	 2
3	3
	 3
4	4
	 4
5	5
	 5
6	6
	 6
7	7
	 7
8	8
	 8
9	9
	 9
P<P	PC Fav / Marker / PC
	
0	0
	 0
--	Guide / EPG / -/--
	
M	Menu / Home
	
i	Info / Angle
	
I-II	Audio / Lang I/II
	

Original	Recharge
 Mute	 Mute / Dimmer
 Left	 Left
 Up	 Up
 Right	 Right
OK	OK
	
 Down	 Down
V -	Vol-
	
V +	Vol+
	
P -	CH- / Page-
	
P +	CH+ / Page+
	
Red / Sound	Red / Netflix / Search
	
Red / Sound	Sound / Title
	
Green / Picture	Green / APP / Repeat
	
Green / Picture	Picture / Format
	
Yellow / Feature	Yellow / YouTube / Repeat
	
Blue / Install	Blue / Prime Video / Random
	
Text	Text / Goto
