
























	Original	Recharge		Original	Recharge
	Power		Power		Ch -
	Subtitle		Subt		Vol +
	Info		Info		Vol -
	Play		Play		Mute
	Pause		Pause		Menu
	<<		<<		Exit
	>>		>>		1
	Record		Rec		2
	Stop		Stop		3
	>>I		>>I		4
	I<<		I<<		5
	OK		Ok		6
	Up		Up		7
	Down		Down		8
	Left		Left		9
	Right		Right		0
	CH+		Ch +		Red



