




Original		Rechange		Original		Rechange	
	On / ST.BY		Power		Info		Info
	TV / Radio		TV/R		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Right		Right
	2		2		Down		Down
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol +		Vol +
	6		6		Vol -		Vol -
	7		7		Prog +		Ch +
	8		8		Prog -		Ch -
	9		9		Red		Red
	0		0		Green		Green
	Text		Text		Yellow		Yellow
	FAV		Pre Ch		Blue		Blue
	Back		Back		Menu		Menu
	EPG		Guide		Audio		Dual





Original	Rechange	Original	Rechange
	Sleep		Sleep
	Sub		Subt
	<< Rew		<<
	Fwd >>		>>
	I<< Prev		I<<
	Next >>I		>>I
	Rec		Rec
	File		Smart
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop

