





































| Original | Recharge |
|--|---|
|  POWER |  Power |
|  INFO |  Info |
|  HDMI CONTROL |  Media |
|  SLEEP |  Sleep |
|  SCREEN |  Format |
|  SOURCE |  AV |
|  PRESETS |  Options |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |

| Original | Recharge |
|--|--|
|  RETURN |  Back |
|  MENU |  Menu |
|  ZOOM/RED/▲ |  Red |
|  REPEAT/GREEN/▼ |  Green |
|  ROOT/YELLOW |  Shift + Yellow |
|  TITLE/BLUE |  Blue |
|  OK/SELECT |  Ok |
|  UP |  Up |
|  DOWN |  Down |
|  RIGHT |  Right |
|  LEFT |  Left |
|  P+ |  Ch + |
|  P- |  Ch - |
|  V+ |  Vol + |
|  V- |  Vol - |
|  FAV |  Pre Ch |
|  LANG |  Dual |



