







































| Original | Recharge |
|---|--|
|  Power |  Power |
|  TV/DTV |  Smart |
|  Source |  AV |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Recall |  Pre Ch |
|  Info |  Info |
|  FAV |  Shift + Pre Ch |
|  Picture |  Shift + Format |

| Original | Recharge |
|---|--|
|  Sound |  Shift + Dual |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  Menu |  Menu |
|  EPG |  Guide |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  I/II |  Dual |
|  Still |  Format |
|  Zoom |  Eject |
|  Exit |  Exit |





| Original | Recharge |
|--------------|--------------|
| Radio | TV/R |
| Next | >>I |
| Lang | List |
| Subtitle | Subt |
| Back | Back |
| Forward | >> |
| Play | Play |
| Pause | |
| Stop | ■ |
| Red | Red |
| Green | Green |
| Yellow | Yellow |
| Blue | Blue |
| Text | Text |
| Size/PIP | 3D |
| Reveal/Swap | Options |
| Cancel/CH Up | Shift + Ch + |

| Original | Recharge |
|----------------|--------------|
| Mix/CH Down | Shift + Ch - |
| Subcode/Source | Shift + AV |
| Index/Position | Media |
| Hold/Sleep | Sleep |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

