



Original	Recharge	Original	Recharge
 Mute	 Mute / Dimmer	 Red / Program	 Red / Netflix / Search
 Power	 Power	 Green / Intro	 Green / APP / Repeat
 S.Mode /	 D.Menu / Top	 Yellow / Repeat	 Shift + Yellow / YouTube / Repeat A-B
 S.Mode /	 Shift + D.Menu / Top Menu	 Yellow / Repeat	 Yellow / YouTube / Repeat
 P.Mode / Title	 Sound / Title	 Blue / A-B	 Blue / Prime Video / Random
 FAV + / Go To	 Shift + CH+ /	 Index / D.Disp.	 Display / Media
 FAV - / Angle	 Shift + CH- /	 Sub-T	 Subtitle / EQ
 <<	 << / Tune-	 Audio / Lang	 Audio / Lang I/II
 Play / Pause	 Play / Slow	 Size / Zoom	 Zoom / Size
 Play / Pause	 Shift + Play /	 Info	 Info / Angle
 >>	 >> / Tune+	 TV / Radio	 TV/Radio /
 Reveal	 Smart / List	 FAV	 Fav / Marker / PC
 I<<	 I<< / Preset-	 Sleep	 Sleep / Timer
 Stop	 Stop / Hold	 Menu	 Menu / Home
 >>I	 >>I / Preset+	 Exit	 Exit / Cancel / Clear
 Rec	 Rec / Rec Mode	 Input	 AV / Input / RDS
 Red / Program	 Shift + Red / Netflix / Search	 EPG	 Guide / EPG / -/-



