







































































| Original  | Recharge    | Original  | Recharge                |
|---|-------------|---|-------------------------|
|      | Smart       |      | Smart / List            |
|      | Power       |      | Power                   |
|      | Mute        |      | Mute / Dimmer           |
|      | 1           |      | 1                       |
|      | 2           |      | 2                       |
|      | 3           |      | 3                       |
|      | 4           |      | 4                       |
|      | 5           |      | 5                       |
|      | 6           |      | 6                       |
|     | 7           |     | 7                       |
|    | 8           |    | 8                       |
|    | 9           |    | 9                       |
|    | CH List     |    | Shift + Smart / List    |
|    | 0           |    | 0                       |
|    | Source      |    | AV / Input / RDS        |
|    | Home        |    | Shift + Menu /          |
|    | Up          |    | Up                      |
|    | Menu        |    | Menu / Home             |
|    | Left        |    | Left                    |
|    | OK          |    | OK                      |
|    | Right       |    | Right                   |
|    | Back        |    | Back / Return           |
|    | Down        |    | Down                    |
|    | Exit        |    | Exit / Cancel / Clear   |
|    | Netflix     |    | Shift + Red / Netflix / |
|    | Google Play |    | Display / Media         |
|   | Vol+        |   | Vol+                    |
|  | [i+]        |  | Info / Angle            |
|  | P+          |  | CH+ / Page+             |
|  | Vol-        |  | Vol-                    |
|  | Guide       |  | Guide / EPG / -/-       |
|  | P-          |  | CH- / Page-             |
|  | <</Reveal   |  | << / Tune-              |
|  | Play/Index  |  | Play / Slow             |



