






































































Original		Rechange		Original		Rechange	
	Power		Power		Left		Left
	Guide		Guide		OK		Ok
	[]		3D		Vol+		Vol +
	Teletext		Text		Vol-		Vol -
	Subtitle		Subt		Mute		Mute
	AV		AV		P+		Ch +
	Red		Red		P-		Ch -
	Green		Green		1		1
	Yellow		Yellow		2		2
	Blue		Blue		3		3
	Menu/Exit		Menu		4		4
	Options		Options		5		5
	Back		Back		6		6
	Info		Info		7		7
	Up		Up		8		8
	Down		Down		9		9
	Right		Right		0		0





Original	Recharge	Original	Recharge
 MPEG/Cancel	 Exit		
 [<>]	 Format		

