



Original	Rechange
Standby	Power
Teletext	Text
Red	Red
Green/[] Smart	Green
Yellow/Smart	Yellow
Blue	Blue
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Clear	Exit

Original	Rechange
Timer	AV
Menu	Menu
Mute	Mute
P<P	Pre Ch
OK	Ok
Up	Up
Down	Down
Right	Right
Left	Left
P+	Ch +
P-	Ch -
Vol+	Vol +
Vol-	Vol -
Play	Play
Stop	Stop
Record/OTR	Rec
<<	<<



