





Original	Recharge
 Power	 Power
 Setup	 Options
 DTV	 D. Menu
 HDMI/AV	 AV
 1	 1
 Disk	 List
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX	 Text
 EPG	 Guide

Original	Recharge
 Movie	 Red
 Music	 Green
 Photo	 Yellow
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Exit	 Exit
 Home	 Smart
 Edit	 TV/R
 Copy	 3D
 Repeat	 Shift + Text
 Rec	 Rec
 Play	 Play



