







































































Original	Recharge	Original	Recharge
 Power	 Power	 Left	 Left
 Mute	 Mute / Dimmer	 OK	 OK
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Back	 Back / Return
 4	 4	 Menu	 Menu / Home
 5	 5	 NETFLIX	 Shift + Red / Netflix /
 6	 6	 YouTube	 Shift + Yellow / YouTube /
 7	 7	 prime video	 Shift + Blue / Prime
 8	 8	 Google Play	 Shift + Green / APP /
 9	 9	 Vol+	 Vol+
 Info	 Info / Angle	 Google Assistant	 Smart / List
 0	 0	 P+	 CH+ / Page+
 EPG	 Guide / EPG / -/--	 Vol-	 Vol-
 Settings	 Setup / OPT /	 Home	 D.Menu / Top
 Input	 AV / Input / RDS	 Home	 Display / Media
 Up	 Up	 P-	 CH- / Page-





Original		Recharge		Original		Recharge	
	Text		Text / Goto				
	USB		Shift + 8				
	I/II		Audio / Lang I/II				
	Subt		Subtitle / EQ				
	Play / Text Mix		Play / Slow				
	Pause		Pause / Step / Freeze				
	Stop / Text Hold		Stop / Hold				
	Text Size		Zoom / Size				
	<< / Text		<< / Tune-				
	I<< / Text Index		I<< / Preset-				
	>>I / Text Reveal		>>I / Preset+				
	>> / Text Cancel		>> / Tune+				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				

