
































































	Original	Recharge
	Power	 Power
	Source	 SRC
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0	 0
	TTX/MIX	 TEXT
	PRE-CH	 P/C / FAV
	Vol+	 VOL +
	Vol-	 VOL -
	Mute	 MUTE

	Original	Recharge
	P+	 CH +
	P-	 CH -
	CH List	 TV/R
	Content	 Shift + VOD
	Menu	 MENU
	Guide	 -/-- / EPG
	Tools	 OPT+
	Info	 INFO
	Return	 BACK
	Exit	 EXIT
	Up	 UP
	Down	 DOWN
	Right	 RIGHT
	Left	 LEFT
	Enter	 OK
	Red	 Red (A)
	Green	 Green (B)





Original		Recharge		Original		Recharge	
	Yellow		Yellow (C)				
	Blue		Blue (D)				
	Media. P		MEDIA				
	Internet/@TV		VOD				
	Dual I-II		Audio				
	AD		WIDE				
	P.Size		V-FOR				
	Subt.		Subt.				
	<<		Rewind				
	Pause		Pause				
	>>		Fast Forward				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

