





































































Original		Rechange		Original		Rechange	
	Standby		Power		10+		Guide / EPG / -/--
	Open / Close		Eject / Surround		Audio		Audio / Lang I/II
	Mute		Mute / Dimmer		Display		Display / Media
	1		1		Return		Back / Return
	2		2		Setup		Setup / OPT /
	3		3		Zoom		Zoom / Size
	Subtitle		Subtitle / EQ		Up		Up
	4		4		Left		Left
	5		5		Enter		OK
	6		6		Right		Right
	Angle		Info / Angle		Title		Sound / Title
	7		7		Down		Down
	8		8		Menu		Menu / Home
	9		9		N/P		Picture / Format
	Prog		TV/Radio /		USB		Shift + 8
	Goto		Text / Goto		Play / Pause		Play / Slow
	10/0		0				





Original

Recharge

	Play / Pause		Pause / Step / Freeze
	I<<		I<< / Preset-
	>>		>> / Tune+
	Stop		Stop / Hold
	>>I		>>I / Preset+
	Repeat		Green / APP / Repeat
	A-B		Yellow / YouTube / Repeat
	Resume		Rec / Rec Mode
	L/R		D.Menu / Top
	Step		Shift + Pause / Step /
	Video Out		AV / Input / RDS
	Clear		Exit / Cancel / Clear
	Vol+		Vol+
	Slow		Shift + Play /
	Shuffle		Blue / Prime Video / Random
	PBC		Smart / List
	Vol-		Vol-

Original

Recharge

