



Original	Rechange
 Standby	 Power
 Teletext	 Text
 Red	 Red
 Green/[ ] Smart	 Green
 Yellow/Smart	 Yellow
 Blue	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Clear	 Exit

Original	Rechange
 Timer	 AV
 Menu	 Menu
 Mute	 Mute
 P<P	 Pre Ch
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Play	 Play
 Stop	 Stop
 Record/OTR	 Rec
 <<	 <<





	Original	Rechange	Original	Rechange
[Fast Forward Icon]	>>	[Fast Forward Icon]		>>
[Index Icon]	> /Index	[Index Icon]		>>
[Still Icon]	> </Still	[Pause Icon]		Pause

