


















| Original | Recharge |
|---|---|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  Play / Pause |  Play / Slow |
|  Play / Pause |  Pause / Step / Freeze |
|  Stop |  Stop / Hold |
|  Rec |  Rec / Rec Mode |
|  <<< |  <<< / Tune- |
|  >>> |  >>> / Tune+ |
|  <<< |  I<<< / Preset- |
|  >>> |  >>>I / Preset+ |
|  :Q |  Sound / Title |
|  TV Play |  Eject / Surround |
|  Format |  Picture / Format |
|  Live TV |  TV/Radio / |
|  ≡ |  D.Menu / Top |
|  ⚙ |  Setup / OPT / |
|  Green / TTX |  Text / Goto |

| Original | Recharge |
|---|---|
|  Source |  AV / Input / RDS |
|  Home |  Menu / Home |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  OK |
|  Del |  Exit / Cancel / Clear |
|  Blue / Info |  Info / Angle |
|  Back |  Back / Return |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Internet |  Smart / List |
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  Mouse |  Display / Media |
|  1 |  1 |





| Original | | Recharge | | Original | | Recharge | |
|--------------|--------------|-----------------------|-----------------------------|----------|--|----------|--|
| 2 | 2 | DVD 2 | 2 | | | | |
| 3 | 3 | CD - STB 3 | 3 | | | | |
| 4 | 4 | VIDEO 4 | 4 | | | | |
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| 0 | 0 | HDMI - BAT 0 | 0 | | | | |
| Red / EPG | Red / EPG | GUIDE EPG | Guide / EPG / -/-- | | | | |
| ←] | ←] | PC FAV MARKER | Fav / Marker / PC | | | | |
| Red / EPG | Red / EPG | NETFLIX SEARCH | Red / Netflix / Search | | | | |
| Green / TTX | Green / TTX | APP REPEAT | Green / APP / Repeat | | | | |
| Yellow / FAV | Yellow / FAV | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | | | |
| Blue / Info | Blue / Info | Prime Video RANDOM | Blue / Prime Video / Random | | | | |
| Yellow / FAV | Yellow / FAV | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC | | | | |

