




Original	Recharge
Power	Power
Prog	TV/Radio /
Subtitle	Subtitle / EQ
Open/Close	Eject / Surround
OSD	Display / Media
PBC	D.Menu / Top
A-B	Yellow / YouTube / Repeat
Repeat	Green / APP / Repeat
3D	Shift + Zoom /
Random	Blue / Prime Video / Random
Slow	Shift + Play /
Clear	Exit / Cancel / Clear
Resume	Sound / Title
Digest	Shift + Subtitle / EQ
Video	Shift + 4
Zoom	Zoom / Size
Setup	Setup / OPT /

Original	Recharge
Return	Back / Return
Up	Up
Left	Left
Enter	OK
Right	Right
Angle	Info / Angle
Down	Down
Language	Audio / Lang I/II
N/P	Picture / Format
Mute	Mute / Dimmer
Vol+	Vol+
R/L	Smart / List
Title	Shift + Sound / Title
Menu	Menu / Home
Vol-	Vol-
Reset	Sleep / Timer
1	1





Original	Recharge
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/10	0
10+	Guide / EPG / -/--
Goto	Text / Goto
<<	<< / Tune-
>>	>> / Tune+
I<<	I<< / Preset-
>>I	>>I / Preset+
Play	Play / Slow
Pause	Pause / Step / Freeze

Original	Recharge
Stop	Stop / Hold
Step	Shift + Pause / Step /

