



Original	Recharge
 Power	 Power
 Mute	 Mute
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Text	 Text
 Zoom	 Eject
 Subt	 Subt
 Audio	 Dual
 Rec	 Rec
 --	 Shift + Guide
 Stop	 Stop
 Play / Pause	 Play
 Play / Pause	 Pause
 <<	 <<
 >>	 >>

Original	Recharge
 I<<	 I<<
 >>I	 >>I
 Menu	 Menu
 FAV	 Pre Ch
 Up / PR+	 Up
 Down / PR-	 Down
 Right / Vol+	 Right
 Left / Vol-	 Left
 OK / List	 Ok
 OK / List	 List
 Exit	 Exit
 EPG	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Info	 Info
 Media	 Media
 Page+	 Ch +



