



| Original | Recharge              |
|----------|-----------------------|
| Power    | Power                 |
| Source   | AV / Input / RDS      |
| 1        | 1                     |
| 2        | 2                     |
| 3        | 3                     |
| 4        | 4                     |
| 5        | 5                     |
| 6        | 6                     |
| 7        | 7                     |
| 8        | 8                     |
| 9        | 9                     |
| TV       | TV/Radio /            |
| 0        | 0                     |
| Recall   | Shift + Back / Return |
| Vol+     | Vol+                  |
| Mute     | Mute / Dimmer         |
| PR+      | CH+ / Page+           |

| Original        | Recharge                  |
|-----------------|---------------------------|
| Vol-            | Vol-                      |
| World/Internet  | Smart / List              |
| PR-             | CH- / Page-               |
| Menu            | Menu / Home               |
| Q.Menu          | D.Menu / Top              |
| Up              | Up                        |
| Left            | Left                      |
| OK              | OK                        |
| Right           | Right                     |
| Down            | Down                      |
| Back            | Back / Return             |
| Exit            | Exit / Cancel / Clear     |
| i               | Info / Angle              |
| Camera/Music/Ph | Picture / Format          |
| Guide           | Guide / EPG / -/-         |
| */o             | Shift + Guide / EPG / -/- |
| */o..           | Fav / Marker / PC         |





|  | Original | Recharge                    | Original | Recharge |
|--|----------|-----------------------------|----------|----------|
|  | [≡]/Text | Text / Goto                 |          |          |
|  | Red      | Red / Netflix / Search      |          |          |
|  | Green    | Green / APP / Repeat        |          |          |
|  | Yellow   | Yellow / YouTube / Repeat   |          |          |
|  | Blue     | Blue / Prime Video / Random |          |          |
|  | Lang     | Audio / Lang I/II           |          |          |
|  | [≡]..    | Shift + Text /              |          |          |
|  | [-o-]    | Setup / OPT /               |          |          |
|  | <<       | << / Tune-                  |          |          |
|  | Pause    | Pause / Step / Freeze       |          |          |
|  | >>       | >> / Tune+                  |          |          |
|  | Rec      | Rec / Rec Mode              |          |          |
|  | Play     | Play / Slow                 |          |          |
|  | Stop     | Stop / Hold                 |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |

