



































| Original | Recharge | Original | Recharge |
|-------------|---|--------------|---|
| PWR On/Off |  Power | Back |  Back |
| Mute |  Mute | Volume+ |  Vol + |
| App |  Media | CH/Page+ |  Ch + |
| Subt.List |  Subt | Volume- |  Vol - |
| Sleep Timer |  Sleep | Audio |  Dual |
| TV |  TV/R | CH/Page- |  Ch - |
| Video |  D. Menu | 1. ? |  1 |
| Text |  Text | 2abc |  2 |
| TV/SAT |  AV | 3def |  3 |
| Menu |  Menu | 4ghi |  4 |
| Menu Up |  Up | 5jkl |  5 |
| Display |  Info | 6mno |  6 |
| Menu Left |  Left | 7pqrm |  7 |
| OK Enter |  Ok | 8tuv |  8 |
| Menu Right |  Right | 9wxyz |  9 |
| Exit |  Exit | Guide Pilote |  Guide |
| Menu Down |  Down | 0/10 |  0 |



