

































































Originale	Sostituto
 Power	 Power
 Source	 SRC
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX/MIX	 TEXT
 PRE-CH	 P/C / FAV
 Vol+	 VOL +
 Vol-	 VOL -
 Mute	 MUTE

Originale	Sostituto
 P+	 CH +
 P-	 CH -
 CH List	 TV/R
 Content	 Shift + VOD
 Menu	 MENU
 Guide	 -/-- / EPG
 Tools	 OPT+
 Info	 INFO
 Return	 BACK
 Exit	 EXIT
 Up	 UP
 Down	 DOWN
 Right	 RIGHT
 Left	 LEFT
 Enter	 OK
 Red	 Red (A)
 Green	 Green (B)





Originale		Sostituto		Originale	Sostituto
	Yellow		Yellow (C)		
	Blue		Blue (D)		
	Media. P		MEDIA		
	Internet/@TV		VOD		
	Dual I-II		Audio		
	AD		WIDE		
	P.Size		V-FOR		
	Subt.		Subt.		
	<<		Rewind		
	Pause		Pause		
	>>		Fast Forward		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

