








































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Vol+	 Vol+
 TV/RAD	 TV/Radio /	 Mute	 Mute / Dimmer
 Input	 AV / Input / RDS	 PR+/Page Up	 CH+ / Page+
 AV Mode	 Picture / Format	 Vol-	 Vol-
 Energy Saving	 Eject / Surround	 PR-/Page Down	 CH- / Page-
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 OK	 OK
 4	 4	 Right	 Right
 5	 5	 Menu	 Menu / Home
 6	 6	 Down	 Down
 7	 7	 Return	 Back / Return
 8	 8	 Red	 Red / Netflix / Search
 9	 9	 Green/Stop	 Green / APP / Repeat
 List	 Smart / List	 Green/Stop	 Stop / Hold
 0	 0	 Yellow/Play	 Yellow / YouTube / Repeat
 Q.View	 Display / Media	 Yellow/Play	 Play / Slow

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 TV	 TV
 TV/RAD	 DVD	 SAT	 SAT
 Input	 AUX	 SLOW	 SLOW
 AV Mode	 STEP-FREEZE	 HOLD	 HOLD
 Energy Saving	 REC MODE	 TUNE-	 TUNE-
 1	 TUNE+	 PRESET-	 PRESET+
 2	 PRESET	 TITLE	 TITLE
 3	 LANG	 EQ	 SURROUND
 4	 SOUND	 AUDIO	 SUBTITLE
 5	 FORMAT	 SIZE	 TIMER
 6	 PICTURE	 ZOOM	 PROGRAM
 7	 SURROUND	 SLEEP	 TV RADIO
 8	 TOP MENU	 OPT-TOOLS	 RDS
 9	 D.MENU	 SETUP	 AV INPUT
 0	 HOME	 ANGLE	 HOME
 LIST	 MENU	 INFO	 MENU
 Q.View	 OK	 OK	 OK
MUTE	CLEAR	EXIT	RETURN
PAGE UP	CANCEL	VOL+	VOL+
PAGE DOWN	LIST	SMART	SMART
MUTE	MEDIA	DISPLAY	DISPLAY
MUTE	CH+	CH PAGE	CH PAGE
MUTE	TV	DVD	DVD
MUTE	VIDEO	TAPE	TAPE
MUTE	AUX - HDD	USB	USB
MUTE	RETURN	BACK	BACK
MUTE	NETFLIX	SEARCH	SEARCH
MUTE	GREEN	APP	APP
MUTE	HOLD	STOP	STOP
MUTE	YELLOW	REPEAT	REPEAT
MUTE	HDMI - BAT	0	0
MUTE	BLUETOOTH	9	9
MUTE	LIST	SMART	SMART
MUTE	HDMI - BAT	0	0
MUTE	MEDIA	DISPLAY	DISPLAY
MUTE	NETFLIX	APP	APP
MUTE	YouTube	REPEAT A-B	REPEAT A-B
MUTE	SLOW	PLAY	PLAY
MUTE	SLOW	PLAY	PLAY



