


























| Originale  | Sostituto   |
|--|---|
|  Power    |  Power                   |
|  Netflix  |  Shift + Red / Netflix / |
|  1        |  1                       |
|  2        |  2                       |
|  3        |  3                       |
|  4        |  4                       |
|  5        |  5                       |
|  6        |  6                       |
|  7        |  7                       |
|  8        |  8                       |
|  9      |  9                     |
|  TV     |  TV/Radio /            |
|  0      |  0                     |
|  Recall |  Fav / Marker / PC     |
|  Vol+   |  Vol+                  |
|  Mute   |  Mute / Dimmer         |
|  PR+    |  CH+ / Page+           |

| Originale   | Sostituto   |
|---|---|
|  Vol-              |  Vol-                    |
|  i                 |  Info / Angle            |
|  PR-               |  CH- / Page-             |
|  Menu              |  Menu / Home             |
|  Up                |  Up                      |
|  Q.Menu            |  D.Menu / Top            |
|  Left              |  Left                    |
|  OK                |  OK                      |
|  Right             |  Right                   |
|  Back              |  Back / Return           |
|  Down            |  Down                  |
|  EXit            |  Exit / Cancel / Clear |
|  World           |  Smart / List          |
|  Camera/Music/Ph |  Display / Media       |
|  Guide           |  Guide / EPG / -/--    |
|  */o             |  Picture / Format      |
|  Games           |  AV / Input / RDS      |





| Originale  | Sostituto   |
|--|---|
|  [=]/Text |  Text / Goto                 |
|  Red      |  Red / Netflix / Search      |
|  Green    |  Green / APP / Repeat        |
|  Yellow   |  Yellow / YouTube / Repeat   |
|  Blue     |  Blue / Prime Video / Random |
|  Lang     |  Audio / Lang I/II           |
|  [=]..    |  Subtitle / EQ               |
|  [-O-]    |  Zoom / Size                 |
|  <<<      |  <<< / Tune-                 |
|           |  Pause / Step / Freeze       |
|  >>>      |  >>> / Tune+                 |
|  Rec     |  Rec / Rec Mode             |
|  ▶      |  Play / Slow               |
|  ■      |  Stop / Hold               |
|  |   |
|  |   |
|  |   |
|  |   |

| Originale | Sostituto |
|-----------|-----------|
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |

