






| Originale   | Sostituto   | Originale   | Sostituto   |
|---|---|---|---|
|  Power         |  Power         |  ♪ |  5 / Audio |
|  Mute          |  Mute          |   |   |
|  Moon          |  1 / Setup     |   |   |
|  Tv Arc.       |  4 / Mode      |   |   |
|  Opt:          |  7 / Rep       |   |   |
|  AUX           |  Source        |   |   |
|  Vol+          |  V+            |   |   |
|  Vol-          |  V-            |   |   |
|  Bass+         |  +             |   |   |
|  Bass-        |  -            |   |   |
|  Voice+      |  Up          |   |   |
|  Voice-      |  Down        |   |   |
|  Play        |  Play / Band |   |   |
|  I<          |  I<          |   |   |
|  >I          |  >I          |   |   |
|  Videocamara |  9 / Disp    |   |   |
|  Playing     |  8 / A-B     |   |   |

