

























Originale	Sostituto	Originale	Sostituto
 Power	 Power	 9	 9
 AV	 AV / Input / RDS	 Info	 Info / Angle
 Mute	 Mute / Dimmer	 Back	 Back / Return
 16:9	 Picture / Format	 0	 0
 Zoom	 Zoom / Size	 Exit	 Exit / Cancel / Clear
 Subt.	 Subtitle / EQ	 Menu	 Menu / Home
 Audio	 Audio / Lang I/II	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 OK
 3	 3	 Right	 Right
 FAV	 Fav / Marker / PC	 Down	 Down
 4	 4	 Vol-	 Vol-
 5	 5	 Vol+	 Vol+
 6	 6	 PR-	 CH- / Page-
 EPG	 Guide / EPG / -/--	 PR+	 CH+ / Page+
 7	 7	 Red	 Red / Netflix / Search
 8	 8	 Green	 Green / APP / Repeat

Originale	Sostituto	Originale	Sostituto
 9	 9	 9	 9
 Info	 Info / Angle	 Info	 Info / Angle
 Back	 Back / Return	 Back	 Back / Return
 0	 0	 0	 0
 Exit	 Exit / Cancel / Clear	 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home	 Menu	 Menu / Home
 Up	 Up	 Up	 Up
 Left	 Left	 Left	 Left
 OK	 OK	 OK	 OK
 Right	 Right	 Right	 Right
 Down	 Down	 Down	 Down
 Vol-	 Vol-	 Vol-	 Vol-
 Vol+	 Vol+	 Vol+	 Vol+
 PR-	 CH- / Page-	 PR-	 CH- / Page-
 PR+	 CH+ / Page+	 PR+	 CH+ / Page+
 Red	 Red / Netflix / Search	 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat	 Green	 Green / APP / Repeat





Originale	Sostituto
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 TXT	 Text / Goto
 ♪	 Sound / Title
 []	 Smart / List
 Swap	 Sleep / Timer
 PIP	 D.Menu / Top
 Pos	 Setup / OPT /
 Size	 +  Shift + Zoom /
 Freeze	 Pause / Step / Freeze

Originale	Sostituto

