







































































| Originale   |        | Sostituto   |                      | Originale   |            | Sostituto   |                            |
|---|--------|---|----------------------|---|------------|---|----------------------------|
|    | Power  |    | Power                |    | 8          |    | 8                          |
|    | Mute   |    | Mute / Dimmer        |    | 9          |    | 9                          |
|    | Info   |    | Info / Angle         |    | Time Shift |    | Sleep / Timer              |
|    | Angle  |   | Shift + Info / Angle |    | 0          |    | 0                          |
|    | Copy   |   | Picture / Format     |    | Goto       |    | Shift + Text /             |
|    | Zoom   |   | Zoom / Size          |    | Rec        |    | Rec / Rec Mode             |
|    | Tv Sys |   | Smart / List         |    | Stop       |    | Stop / Hold                |
|    | Music  |   | Sound / Title        |    | Subtitle   |    | Subtitle / EQ              |
|    | Setup  |   | Setup / OPT /        |    | Audio      |    | Audio / Lang I/II          |
|    | Menu   |   | Menu / Home          |    | <</FR      |    | << / Tune-                 |
|   | 1      |   | 1                    |   | >>/FF      |   | >> / Tune+                 |
|  | 2      |  | 2                    |  | A-B        |  | Shift + Yellow / YouTube / |
|  | 3      |  | 3                    |  | Repeat     |  | Shift + Green / APP /      |
|  | 4      |  | 4                    |  | >>I/Next   |  | >>I / Preset+              |
|  | 5      |  | 5                    |  | Vol+       |  | Vol+                       |
|  | 6      |  | 6                    |  | Play/Pause |  | Play / Slow                |
|  | 7      |  | 7                    |  | Vol-       |  | Vol-                       |



