








































































Originale	Sostituto
 Power	 Power
 Menu	 Menu
 Q.Menu	 D. Menu
 Exit	 Exit
 Back	 Back
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -

Originale	Sostituto
 PR +	 Ch +
 PR-	 Ch -
 i	 Info
 Guide/Tv+Book	 Shift + Options
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Pre Ch
 TV	 TV/R
 [≡]/Text	 Text





Originale	Sostituto	Originale	Sostituto
 */o..	 Eject		
 Source/Game	 AV		
 */o	 List		
 World	 Guide		
 Music/Movie/Phot	 Options		
 [-O-]	 Sleep		
 [≡]..	 Subt		
 Lang	 Dual		
 Rec	 Rec		
 Stop	 Stop		
 Pause	 Pause		
 Play	 Play		
 >>	 >>		
 <<	 <<		

