



































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 CH+	 Ch +
 2	 2	 CH-	 Ch -
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 Red	 Red
 6	 6	 Yellow	 Yellow
 7	 7	 Blue	 Blue
 8	 8	 Green	 Green
 9	 9	 EPG	 Guide
 0	 0	 Subtitle	 Subt
 Menu	 Menu	 TTX	 Text
 Exit	 Exit	 Audio	 Dual
 Up	 Up	 i	 Info
 Down	 Down	 FAV	 Pre Ch
 Right	 Right	 Tv/Radio	 TV/R

Originale	Sostituto	Originale	Sostituto
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 Play	 Play	 Pause	 Pause
 Stop	 Stop	 FF	 FF
 FR	 FR	 SETTINGS	 SETTINGS
 DISC NAV	 DISC NAV	 SOUND	 SOUND
 LIST	 LIST	 SUBT	 SUBT
 PROG	 PROG	 PICTURE	 PICTURE
 SLEEP	 SLEEP	 ECO	 ECO
 E-MANUAL	 E-MANUAL	 3D	 3D
 D.MENU	 D.MENU	 TIMER	 TIMER
 TOP MENU	 TOP MENU	 DISPLAY	 DISPLAY
 MENU	 MENU	 INFO	 INFO
 CLEAR	 CLEAR	 OK	 OK
 EXIT	 EXIT	 RETURN	 RETURN
 HOME	 HOME	 BACK	 BACK
 SMART	 SMART	 APP	 APP
 MEDIA	 MEDIA	 VOL +	 VOL +
 VOL -	 VOL -	 CH +	 CH +
 1	 1	 CH -	 CH -
 2	 2	 HOME	 HOME
 3	 3	 MEDIA	 MEDIA
 4	 4	 GUIDE	 GUIDE
 5	 5	 0	 0
 6	 6	 PRE-CH	 PRE-CH
 7	 7	 A	 A
 8	 8	 B	 B
 9	 9	 C	 C
 GUIDE	 GUIDE	 D	 D
 0	 0	 Mandis SHOP	 Mandis SHOP
 PRE-CH	 PRE-CH	 www.mandis.tv	 www.mandis.tv



