



Originale	Sostituto
 Power	 Power
 Play	 Play
 Pause	 Pause
 <<<	 <<<
 >>>	 >>>
 <<<	 <<<
 >>>	 >>>
 Stop	 Stop
 Rec	 Rec
 Tv/TXT	 Text
 Cancel	 Back
 Reveal	 D. Menu
 Hold	 Options
 Size	 Eject
 Subpage	 Shift + Subt
 Index	 Info
 Red	 Red

Originale	Sostituto
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Source	 AV
 Menu	 Menu
 DVB	 Smart
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 1	 1





Originale	Sostituto	Originale	Sostituto
2	2	FAV	Shift + Pre Ch
3	3	FAV+	Shift + Ch +
4	4	FAV-	Shift + Ch -
5	5	Subtitle	Subt
6	6	Pic Format	Format
7	7	Language	Dual
8	8	EPG	Guide
9	9	Text	List
0	0	Display	3D
-/--	Shift + Guide		
Recall	Pre Ch		
Picture	Shift + Format		
Sound	Shift + Dual		
Nicam/A2	Media		
Mute	Mute		
Sleep	Sleep		
Tv/Radio	TV/R		

Originale	Sostituto	Originale	Sostituto
FAV	Shift + Pre Ch		
FAV+	Shift + Ch +		
FAV-	Shift + Ch -		
Subtitle	Subt		
Pic Format	Format		
Language	Dual		
EPG	Guide		
Text	List		
Display	3D		

