



























































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Yellow		Yellow
	Play		Play		Index		List
	Pause		Pause		Blue		Blue
	<<		<<		CH+		Ch +
	>>		>>		CH-		Ch -
	I<<		I<<		Input		AV
	>>I		>>I		Vol+		Vol +
	Stop		Stop		Vol-		Vol -
	Rec		Rec		Mute		Mute
	Tv/TXT		Text		Menu		Menu
	Cancel		Shift + Exit		Exit		Exit
	Hold		Options		DVB		Smart
	Reveal		D. Menu		Up		Up
	Size		3D		Down		Down
	Red		Red		Right		Right
	Green		Green		Left		Left
	Subpage		Eject		OK		Ok





Originale	Sostituto
	
	
	
	
	
	
	
	
	
	
	 Shift + Guide
	 Back
	 Shift + Format
	 Shift + Dual
	 Media
	 Sleep
	 TV/R

Originale	Sostituto
	 Pre Ch
	 Shift + Ch +
	 Shift + Ch -
	 Subt
	 Format
	 Dual
	 Shift + Text
	 Guide
	 Info

