





















































































Originale	Sostituto
 Power	 Power
 [+]	 Picture / Format
 [i+]	 Info / Angle
 <</<l	 << / Tune-
 Play Bravia Sync	 Play / Slow
 Pause Bravia	 Pause / Step / Freeze
 >>/l>	 >> / Tune+
 Sync Menu Bravia Sync	 D.Menu / Top
 Stop Bravia Sync	 Stop / Hold
 Theatre Bravia	 TV/Radio /
 Digital	 Display / Media
 Analog	 Smart / List
 [...] Audio	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 Guide	 Guide / EPG / -/--
 Source	 AV / Input / RDS
 Return	 Back / Return

Originale	Sostituto
 Options	 Setup / OPT /
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 Home	 Menu / Home
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6





	Originale	Sostituto		Sostituto
	7		7	
	8		8	
	9		9	
	0		0	
	Text		Text / Goto	
	FAV		Shift + Fav / Marker / PC	
	Vol+		Vol+	
	Vol-		Vol-	
	Mute		Mute / Dimmer	
	Prog+		CH+ / Page+	
	Prog-		CH- / Page-	
	Back		Fav / Marker / PC	

	Originale	Sostituto

