




































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		6		6
	Mute		Mute		7		7
	DTV/Radio		TV/R		8		8
	Info		Info		9		9
	Tv Audio		Dual		0		0
	ATV/DTV		Smart		AVC		Media
	Sleep		Sleep		Return		Back
	Sound		Shift + Dual		Prog+		Ch +
	Picture		Shift + Format		Guide		Guide
	Freeze		Pause		Prog-		Ch -
	Subtitle		Subt		[≡..]/List		Shift + List
	Wide		3D		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Exit		Exit
	3		3		Favorite		Pre Ch
	4		4		Up		Up
	5		5		Down		Down





Originale		Sostituto		Originale		Sostituto	
	Right		Right				
	Left		Left				
	OK		Ok				
	Input		AV				
	Menu		Menu				
	[≡+]/Hold		Options				
	[≡x]/Update		Eject				
	[≡o]/Subcode		Shift + Options				
	[.≡]/Text/Mix		Text				
	[≡?]/Reveal		D. Menu				
	[≡i]/Index		Shift + Info				
	List		List				
	Red		Red				
	[≡♦]/Size		Format				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

